

PETZAP CONTACT PADS



REQUIRED: 1 Ace (tensor) bandage [This is a long, stretchy elastic fabric used for bandaging muscle strains, and can be found in most pharmacies].

I. PREPARE THE ZAPPER

1. Plug the included cable into your AutoZap 5.
2. At the other end of this cable are two shiny metal pins. Insert one pin into the grooved channel that runs down the center of one PetZap pad. Then, insert the other pin into the other PetZap pad.

II. PREPARE THE PET

1. Using a damp sponge with warm water, dampen the fur where the PetZap pads will be placed on opposite sides of the animal's body. This will provide conductivity for the zapping session. The PetZap Contact Pads should be placed on either side of the pet's ribcage.
2. Hold PetZap Contact Pads against the pet. As you place the Pet Contacts on the pet where you have just dampened the fur, with slight tension, wrap the Ace bandage over the contact pad and continue wrapping around the body of the pet comfortably. This may require practice, and it helps if your animal is well-trained to sit still.
3. Adjust for comfort. If the tensor bandage is too tight, unwind and re-wrap as required to obtain a comfortable amount of pressure that maintains contact with the pads against the pet.

III. SECURE WIRING AND AUTOZAP 5

1. The AutoZap 5 should now be connected via the cable to the PetZap Contact Pads under the tensor bandage. Gather the extra cable length and tuck it under the back of the Ace bandage, along with the zapper. Begin zapping. The green SensAlert light should shine to show that the Zapper is properly connected to your pet, and the pet's fur is damp enough.
2. At the end of the Zapping session, carefully unwrap the Ace bandage and the contacts from your pet.
3. Be creative. If you have a larger animal, an unusually active or other difficult situation, you may need to be creative.